

Washington Pools 1660 London Line, Sarnia 519-336-3434 kelly@washingtonpools.ca

Hot Tub water test performed for :

Washington: 519-336-3434 @ 1660 London Line, Sarnia, Ontario, N7T7H2

Hot	Tub	Info

Steps to Take Following Fresh Fill

Volume: 1000 Litre Acrylic/Thermoplastic

Your Saturation Index is -0.40. **Saturation Index** is an <u>overall</u> measure of water balance. The acceptable range is -.5 to +.5. Outside this range can lead to corrosion or scale-formation. Follow the detailed instructions below to correct any individual water balance issues and/or resolve other hot tub water problems. Read product label directions carefully before using any recommended product.

Water Test Information

Date: 2024-05-03 Test Type: Fresh Fill

Algae/Biofilm: No Turbidity/Cloudy: No

Temp.: 38.00 °C TDS: 100 ppm

System Used: Mineraluxe System

Sanitizer: Bromine Tablets

Total	Free	Ideal(ppm)
0.9		3-5
pH: 7.5		7.4 - 8.0
Actual(ppm)		Ideal(ppm)
TA: 70		125-150
Ca: 70		100-200
Cu: 0.0		0
Fe: 0.0		0
Mn: 0.0		0

dqq 0

Step 1: Add 2 Mineraluxe CUBE(S) initially.

Step 2: Add <u>1 pouch(es)</u> of Mineraluxe OXYGEN.

Step 3: Balance Water as per Water Balance section.

Add 140 gms of Dazzle Alkalinity Plus. Wait 1 Hour.

Add 4 gms of Dazzle pH Minus. Wait 1 Hour.

Add 80 gms of Dazzle Calcium Plus. Wait 3 Hours.

1/2 Cup / 2 1/2 Caps Balance Pak 100

1/2 Tsp / Lo 'n Slo

13 Tsp / 1 1/2 Caps Balance Pak 300

Step 4: Use MINERALUXE BROMINE TABLETS.

Step 5: Clean your filter.

General Product Application Instructions:

Refer to label directions for each product to be added.

Always add products sparingly and evenly across the water surface.

Always add products with the pump running and the aeration off.

Follow proper wait times between additions for best results.

© 2008-2024
Backyard Brands Inc.
All Rights Reserved
www.DazzleWaterCare.com
(www.dazzlewatercare.com)

Po: 0 ppb

